

PLEASE READ THE FOLLOWING PRIOR TO OPERATION OF THIS EQUIPMENT!

The following are basic safety precautions to understand when operating this skidsteer tractor. It is NOT intended to be a complete list of safety precautions. Please review the Operator Manual prior to operation. If one is not on the machine, contact All Star Rents and we will supply one to you.

Basic Operation & Safety Requirements



This symbol means: **Attention! Be Alert! Your safety is involved!** The safety alert symbols found on decals and in the Operator Manual alert you to potential safety hazards. Obey all safety messages with this symbol to avoid possible injury or death.

Other similar symbols: **⚠️ WARNING** **⚠️ DANGER** **⚠️ CAUTION**



Refer to the Operator Manual for any operational or safety questions you may have. Contact All Star Rents prior to operation if one is not located on the machine. If you are new to operating this machine you should practice in a safe area and refer to Operator Manual for instructions.

Use caution when operating on uneven terrain. Avoid any slopes where the machine could fall over. Avoid side hill work (downhill to left or right as opposed to in front or behind), as this is the most common cause of overturning. Understand that "soft" ground conditions can allow tractor to shift and tilt. **Keep the bucket or any implement on the tractor at the lowest possible position!** Any damage as a result of a machine tipping off either track is not covered by the Equipment Protection Plan.

 56030	CARRY LOAD LOW	 SW 03 6737040	KEEP LOAD LEVEL WHEN RAISING LIFT ARMS
 56030	When backing up, look behind in the direction of travel.	 56030	Carry Load Low. Do not exceed rated operating capacity.
 56030	Move controls smoothly. Do not jerk controls.	 56030	Stop engine.
TO LEAVE LOADER: <ol style="list-style-type: none">1 Lower lift arms and attachment flat on the ground.2 Disengage auxiliary hydraulic system.3 Engage parking brake.4 Stop engine. SW 03 6737039			
 56030	⚠️ WARNING AVOID INJURY OR DEATH	 56030	Keep heavy end uphill. Travel up and down slopes not across them.
 56030		 56030	Never drive over obstructions.
 56030		 56030	Never back over obstructions, drop offs, or uneven ground with lift arms raised. SW 03 6737041
DANGER AVOID DEATH <ul style="list-style-type: none">• Keep out of this area when lift arms are raised.• Disconnecting or loosening any hydraulic tubeline, hose, fitting or part can cause lift arms to drop.• Attachment can be forced against the ground and cause front of machine to raise.• Always use an approved lift arm support device. SW 01 6732142			
 B-23024	CORRECT	 B-23048	WRONG
⚠️ Do not travel or turn with lift arms up.		⚠️ Never exceed Rated Operating Capacity.	
 B-23050	WRONG	 B-23047	WRONG
⚠️ Keep heavy end uphill.		⚠️ Never drive over drop offs or jerk on the controls.	
⚠️ Never drive over drop offs or jerk on the controls.		⚠️ Keep load level when raising lift arms.	

NEVER allow riders anywhere on the machine!
CALL 811 prior to excavation!

Be aware of others around you. Maintain a safe distance from bystanders at all times. Always look in the direction of travel. Buckets and other implement present a crushing and impact injury danger.



Contact All Star Rents immediately if you have any problems with the machine. DO NOT attempt to repair, upright or start the machine if it has tipped over. Doing so could result in further injury or damage to the equipment. Call 911 first if serious injury as occurred while operating the tractor.

All Star Rents Toll Free: 866-ALL STAR